

# WASP

# WIRELESS SCANNER PROGRAMMING CHART

1. ENTER SETUP



2. RESTORE FACTORY DEFAULTS



3. UPDATE



4. WAIT 10 SECONDS FOR LIGHT ON TOP TO STOP BLINKING

5. ENTER SETUP



6. BEEPER FREQUENCY 1 KHz



7. CAPS LOCK ON



8. COMPUTE CODE 39 CHECK DIGIT



9. DO NOT TRANSMIT CODE 39 CHECK DIGIT



10. UPDATE



11. WAIT 10 SECONDS FOR LIGHT